

CST-R80 Series Instruction Manual

Head office, factory : 20-1 Shinomiya Narano-cho, Yamashina-ku, Kyoto 607-8032, Japan
Telephone : +81-75-581-7111
FAX : +81-75-581-7118

- The CST-R80 series sensors identify color and brightness of light sources like LED or color lamp and perform color matching.
- Easy teaching by setting buttons. External inputs can be used as an alternative.
- Equipped with two outputs : Color (RGB) composition matching and brightness matching.
- The tolerance of color composition and brightness can be separately set.

1 SPECIFICATIONS

Output type		NPN	PNP
Model		CST-R80	CST-R80PN
Detection method		RGB color composition / Brightness	
Detection distance		Variable according to the receiving light intensity (※1)	
Power supply		12 to 24VDC $\pm 10\%$, Ripple 10% Max.	
Current consumption		50 mA (Max.)	
Standard color		Teaching, 1 color	
External input for teaching		Non voltage input (contact, non contact)	
Output mode	Output	RGB composition (Output1) / Brightness (Output 2)	
	Output 1	NPN open collector output Sink current 50mA (30VDC) Max.	PNP open collector output Source current 50mA (30VDC) Max.
	Output 2	Residual voltage : 2V	Residual voltage : 2V
Operation mode		Match On / Match Off, selectable	
Delay time		Selectable : On delay / Off delay / Timer disabled Delay time : 250ms fixed	
Response time		Lights up : 50ms or less / Lights down : 100ms or less (※2)	
Indicators		Operation indicator "OP" : When the output is activated Level indicator "H" : Excessive light intensity "L" : Insufficient light intensity	
Display		1 orange digit indicator + 3 red digit indicators	
Mode Switch		RUN : RUN mode / Setting mode, switchover SELECT : SELECT mode / SET mode, switchover +/- : Change the tolerance value and setting item	
Protective feature		Short circuit protection	
Materials		Polycarbonate	
Cable		Flying lead 2m (outer dia $\phi 3.7$)	
Weight (Max.)		60 g	
Attachments		Bracket, Instruction manual	


- ※1 Use within the range so that level indicators H and L are both turned off.
※2 The sensor is activated 1 second after it is powered on.
Response time may change depending on the amount of ambient lights.
Recommended fiber : FT105BC-CS, detecting range : 5mm or less

2 ENVIRONMENTAL CHARACTERISTICS


Ambient light	1,000 lx Max.
Temperature range	10 to 40°C
Humidity	35 to 85%RH
IP rating	IP40
Vibration resistance	10 to 55Hz, 1.5mm double amplitude, 2 hr. in X, Y and Z directions
Shock	500 m/s ² 3 times in X, Y and Z directions

3 WIRING

● CST-R80 (NPN output)



● CST-R80PN (PNP output)




● Precautions when wiring

- Insulate unused input and output lines.
- For the extension cord, use a cord with diameter of more than 0.3mm² and length less than 100m.
- Set the force to be applied to the cords according to the following standard : Tension : 70N or less Torque : 0.8N·m
Pressing force : 20N or less Flexion : 3kg or less
- When the load and the sensor have the own power supply separately, be sure to power on the sensor first.
- When powering off, output pulses may be generated. Be sure to power off the load or the load line first.
- Before attaching or removing the amplifier, be sure to power off.
- Be sure to route the sensor lines separately from any power transmission or high-voltage line. Using the same conduit or duct for wiring may cause electric induction, which leads to faulty operation or damage.


4 AMPLIFIER UNIT INSTALLATION

How to attach / remove case cover


- 1) How to open case cover
Pull up a case cover tab with holding the front part of the case cover.



- 2) How to remove case cover
Push the cover end with full-opened condition and the cover.





- 3) How to attach case cover
Put the cover on an amplifier unit and push a hinge shown on the figure.




How to install DIN rail / mounting bracket

- 1) How to attach
Engage a front hook of the amplifier unit onto a rail (or a mounting bracket) and press a rear part of the amplifier unit.
- 2) How to detach
Lift up the front with pushing the amplifier unit forward, and the hook will be released.




- 3) Side mounting of Amplifier unit
Fasten with screws by making use of the attached mounting bracket. The tightening torque should be 0.8N·m Max.




5 FIBER UNIT INSTALLATION

How to insert Fiber unit to Amplifier unit

- 1) Make a one-touch locking lever go down.
- 2) Push a fiber unit all the way.
You can find some marks on the case side showing the insertion length. Please make use of them as a gauge to avoid a mistake when inserting the fiber unit.
- 3) After the fiber unit is inserted, raise the locking lever until you hear the locking click.



6 OPERATION PANEL



Panel Parts Descriptions

● Indicators

Operation indicator (OP) : Lights when output turns ON.

Level indicator (H)

: Lights when the received light amount becomes saturated.

Level indicator (L)

: Lights when the received light amount becomes insufficient.

※ When the level indicator (H) or (L) is lit, the light amount is beyond or under the measurable range. Adjust the light amount or distance so that the light amount stays within the measurable range.

● Digital display : 1 digit in orange + 3 digits in red.

RUN mode : 1 digit in orange : No indication when color composition is indicated. Indicates "U" or "d" for brightness.

3 digits in red : Indicates a numeric value.

※ The value appears slowly to have better visibility.

● RUN switch

: Changes between the RUN mode and the setting mode.

● SELECT switch

: Changes between the SELECT mode and the SET mode.


● + and - buttons

: Changes the tolerances and setting items.

7 INDICATIONS DURING RUN MODE

7.1 Digital display during RUN mode

"+" and "-" button switch the indication : Color composition / Brightness



· When color composition is displayed :

The digital display shows the difference from the standard with the range from 0 to 999. The closer to the standard the sensed value is, the smaller the displayed value shows.

0 ← close → far → 999
standard (color value)

· When brightness is displayed :

The digital display shows the difference from the standard with the range from -999 to +999. The closer to the standard the sensed brightness is, the closer to zero the displayed value becomes.

-999 ← far (too dark) → standard (brightness) → +999
far (too bright)



"d" is indicated when the current value is below standard.



"U" is indicated when the current value exceeds standard.

7.2 Operation indicator during RUN

Output OFF	Output ON
Unlit	Lit

※ The indicator lights when both or either output is activated.

7.3 Received light amount indicators



These indicators show whether the received light amount is within the measurable range or not. If H or L is lit, the light amount is beyond or below the measurable range. Adjust the light amount or distance so that these indicators turn off.

8 TEACHING

● Refer to 9. DETAIL SETTINGS for setting details.

● Make teaching for color composition and brightness at the same time.

● Factory set for tolerance is 100 for color composition and -100 to +100 for brightness.

1) Registering the standard through the key operation on the sensor unit (Teaching)

Status	Operation	Switch	Display	Work
RUN mode			"999" lights. Note 1	
Setting mode	Change the RUN switch to the setting mode.		The orange indicator blinks. Note 2	A work should be placed
Teaching	Hold down the + or - button (until "End" appears)		"t---" blinks.	
Teaching Completed			"End" lights.	
Setting mode	Release the button.		The indicator in orange blinks.	
RUN mode	Change the RUN switch to the RUN mode.		The current value appears. The operation indicator (OP) lights. Output ON	A work should be placed

Note 1 : Factory-set or after being initialized, the display shows "999".

Note 2 : Teaching can be done only when output 1 (1ch) is selected.

2) Registering the standard using the external output (Teaching)

Status	Operation	Switch	Display	Work
RUN mode			"999" lights. Note 1	A work should be placed
Teaching	Enter external input signals for more than 7 seconds.		"t---" blinks.	
Teaching Completed	After 7 seconds has passed		"End" lights.	
RUN mode	Release external input signals.		The current value appears. The operation indicator (OP) lights. Output ON	A work should be placed

Note 1 : Factory-set or after being initialized, the display shows "999".

※ Teaching errors

If the Err indication appears in the digital display after teaching, an error has occurred.

If this happens, the basic colors do not change but hold the previous values.

During the error is displayed, no output is performed. Press the + or - button to reset.

Teaching error
"Err" blinks.
The input value of received light amount is out of the range. Check the high (H) and low (L) received light amount indicators. Adjust the settings so that both indicators will go off.

9 | DETAIL SETTINGS

In the setting mode following functional settings are available.


※ The indicated numeric value like tolerances and received light amounts are just samples and it may be different from real ones.

The indications are based on factory-set.


The color composition and brightness can be set seperately.

Output 1 : Color composition

Output 2 : Brightness



Tolerance (txxx) xxx : value	Set the tolerance value from standard color composition and brightness. 0 ←————→ 999 small big
Operation mode (C on) (CoFF) operation.	Select "match ON" or "match OFF" for relay operation.
Off delay (FoFF) (F on)	Set OFF DELAY on or off for the output.
On delay (NoFF) (N on)	Set ON DELAY on or off for the output.
Receiving light amount monitor	Light amount is indicated for each RGB components. 0 ←————→ 999 dark bright



10 INITIALIZING THE MODE

Setting and standard color information are reset.

Status	Operation	Switch	Display
RUN mode		SELECT SET RUN	 "999" lights. Note 1
↓	Initializing mode	Change the RUN switch to SET mode while holding down the — button.	 "2out" blinks.
↓	Initializing	Holding down the + or — button for more than 3 seconds.	 "rst" blinks.
↓	Initializing mode	Release the + or — button.	 "2out" blinks.
↓	RUN status	Change the RUN switch to RUN.	 "999" lights. Note 1

Note 1 : Factory-set or after being initialized, the indicator shows "999"

Setting at factory : After being initialized :


Tolerance : 100 (color composition) / -100 to +100 (brightness)

Operation mode (Conform) : ON when matching


Off delay : None

On delay : None


12 DIMENSIONS (unit : mm)



Model : FT105BC-CS (optional)




Model : CS-ND (optional)




11 PRECAUTIONS

- The CST-R80 series may be affected by the ambient light. Do not use the sensor in environments subject to fluctuation of brightness such as the vicinity of windows.
- If the ambient light is brighter than the light source of the work to be detected, the detecting ability may become unstable. Maximize the brightness of the light source of the work to be detected and place the fiber unit as close as possible to the light source.
- For high brightness light sources, use CS-ND light alternation unit.
- Use the fiber unit having a large core diameter for stable detection. Recommended fiber : FT105BC-CS (core diameter 1.5)
- Since the light of fluorescent lamps blink at high rate, the sensor detects the light unstably in environments where the light source of the work to be detected is illuminated with the fluorescent light. Keep the fluorescent light as far away as possible from the light source of the work. The conventional fluorescent lamps are more likely to be affected than the inverter fluorescent lamps.
- The sensor operation may become unstable and generate chattering depending on the installation environments and conditions. On-delay timer or off-delay timer, may reduce generation of chattering.
- The hysteresis level corresponds to the tolerance. The greater the tolerance becomes, the higher the hysteresis level and the less chattering.
- Increase or decrease the tolerance as required using the factory set as a reference.
- Do not use the sensor outdoor or at a site where its light receiving surface is directly exposed to ambient light.

Light receiving amount – Response time (typical correlation)
(Ambient light : 100 lx)



Ambient light – Response time (typical correlation)



- The guarantee period of this product is one year after the delivery.
- If any defect is found during the guarantee period, Takenaka will repair or replace the defective product.
- This product is an industrial sensor which issues an output upon detecting an object. It does not have any function to prevent accidents, death or injuries.
- Takenaka will not held responsible for any damage or loss incurred due to accidents, faulty installation, abuse, misuse, improper maintenance or acts of God including lightning surge.